

New Shape, New Style...
The New Telis Collection





MOTOR INSTRUCTIONS


This semi-cassette awning includes a Somfy Altus RTS remote control motor and the added feature of the newly improved Eolis 3D remote wind sensor. Please follow the factory visual reference guide (below) when setting your limit switches and adding your sensors.

ALTUS 6 STEP VISUAL REFERENCE GUIDE



STEP 1
Initiate programming by pressing both the **Up** and **Down** buttons at the same time until the motor jogs.

NOTE: After every command, the motor will jog to confirm.



STEP 2
Check the directions by pressing the **Up** or **Down** buttons (the motor will work in momentary function). To change the direction, press and hold the **Stop** button until the motor jogs.



STEP 3
Bring the motor to the desired upper limit. Now press both the **Stop** and **Down** buttons until the motor moves, then release. Stop the motor where the lower limit should be set, you can adjust by pressing the **Up** or **Down** buttons.



STEP 4
Press and hold the **Stop** and **Up** buttons until the motor moves up. The motor will stop at the original upper limit point. Adjust if necessary.



STEP 5
Press and hold the **Stop** button until the motor jogs to confirm the limit setting.



STEP 6
Press and hold the **Program** button on the back of the transmitter until the motor jogs. It will now operate in a maintained function. Double check limits as a precaution.



TO ADJUST LIMITS

To change the lower limit: Move the motor to its current lower limit position and let it stop. Press the **Up** and **Down** buttons simultaneously until the motor jogs, then release. Adjust to a new lower limit position. Press the **Stop** button until the motor jogs, then release. Check new limit.

To change the upper limit: Move the motor to its current upper limit position and let it stop. Press the **Up** and **Down** buttons simultaneously until the motor jogs, then release. Adjust to a new upper limit position. Press the **Stop** button until the motor jogs, then release. Check new limit.



To add a remote/channel or sun and wind sensor: First press the programming button on the back of the already programmed remote until the motor jogs. Then press the programming button on the remote or wind sensor that you would like to add until the motor jogs.

To reset the motor: You will need to disconnect power (120vac) for 2 seconds, reconnect for 10 seconds, disconnect for another 2 seconds and reconnect. The motor should start to move and then stop on its own (If this does not happen, continue to perform the disconnects until it does). Once the motor stops moving on its own, press and hold the programming button on the back of the remote and count to ten without letting go. The motor should jog twice.

Please contact SOMFY for detailed installation instructions.

